



Grass Nexis Soft Close Adapter Adjustments

Your soft close adapters installed on the doors hinges are designed to make a door briefly hesitate before closing completely. To ensure you adapters are properly set please follow the simple instructions below.

- Twist the adjustment screw (located on the backside of adapter) counter clockwise to release the bumper pressure off the door. The adjustment screw should roughly reveal 1/8-1/4" of the threads.
 - *if the adapter adjustment screw is set to the maximum setting (screw completely tightened in), the adapter will apply too much force on the baseplate causing the baseplate to break or the hinge to function improperly).*
- Also ensure the door is shut properly. With extra swing pressure or "slamming" the door will cause additional force, causing the adapter to over compensate and possibly break the baseplate or cause other features to work improperly.